


# AIRBRUSH PARTS

• DH-1 / DH-2 / DH-3 / DH-101 / DH-102 / DH-103



No:	Part #	Description
1	<a href="#">PART1</a>	Needle Cap
2a	<a href="#">2-.2mmNozzleCap</a>	.2mm Nozzle Cap
2b	<a href="#">2-.3mmNozzleCap</a>	.3mm Nozzle Cap
2c	<a href="#">2-.35mmNozzleCap</a>	.35mm Nozzle Cap
2d	<a href="#">2-.5mmNozzleCap</a>	.5mm Nozzle Cap
3a	<a href="#">3-.2mmNozzle</a>	.2mm Nozzle
3b	<a href="#">3-.3mmNozzle</a>	.3mm Nozzle
3c	<a href="#">3-.35mmNozzle</a>	.35mm Nozzle
3d	<a href="#">3-.5mmNozzle</a>	.5mm Nozzle
4	PART4	Body
5	<a href="#">PART5</a>	Piston
6	<a href="#">PART06</a>	Push Button Trigger
8a	<a href="#">PART8-.2mm</a>	.2mm O Ring for Needle Guide
8b	<a href="#">PART8-.3mm</a>	.3mm O Ring for Needle Guide
8c	<a href="#">PART8-.35mm</a>	.35mm O Ring for Needle Guide
8d	<a href="#">PART8-.5mm</a>	.5mm O Ring for Needle Guide

No:	Part #	Description
9	<a href="#">PART09</a>	Needle Guide Screw
11	<a href="#">PART11</a>	Needle Chucking Guide
12	<a href="#">PART12</a>	Needle Spring
13	PART13	Spring Case
19	<a href="#">PART19</a>	Piston O Ring
20	PART20	Air Valve O Ring
21	<a href="#">PART21</a>	Air Valve
22	PART22	Hose Connector Nut
24	<a href="#">PART24</a>	Wrench
25a	<a href="#">25.2mmNEEDLE</a>	.2mm Needle
25b	<a href="#">25.3mmNEEDLE</a>	.3mm Needle
25c	<a href="#">25.35mmNEEDLE</a>	.35mm Needle
25d	<a href="#">25.5mmNEEDLE</a>	.5mm Needle
26	<a href="#">PART26</a>	Needle Chucking Nut
27	PART27	Handle