



Item No.	Part No.	Description	Item No.	Part No.	Description
23	2610014582	Nut	651	Dremel 3 Jaw Chuck #4486	Chuck
24	Dremel Collet 3.2mm #480	Contour Sleeve	653	Charger Power Adaptor	Battery Charger
26	2610Z09808	Locking Assembly	801	2610Z09807	Motor Assembly
27	2610Z09809	Assembly Set	805	2610Z09810 Deleted By Dremel	Power Cable
37	2610Z09805 Deleted by Dremel	Screw	821	2610Z09806	On-Off Switch