


Dremel does not supply spare parts for the Workstation.

# DREMEL®

MODEL: 220-01



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	2 615 294 200	Base	16	2 615 294 215	Collar
2	2 615 294 201	Screw	17	2 615 294 216	Screw
3	2 615 294 202	Column	18	2 615 294 217	Knob
4	2 615 294 203	Nut	19	2 615 294 218	Washer
5	2 615 294 204	Nut	20	2 615 294 219	Cover
6	2 615 294 205	Screw	21	2 615 294 220	Housing
7	2 615 294 206	Support Bracket	22	2 615 294 221	Nut
8	2 615 294 207	Pinion	23	2 615 294 222	Screw
9	2 615 294 208	Collar	24	2 615 294 223	Nut
10	2 615 294 209	Shaft	25	2 615 294 224	Holder

11	2 615 294 210	Knob	26	2 615 294 225	Grommet
12	2 615 294 211	Spring	27	2 615 294 226	Screw
13	2 615 294 212	Nameplate	28	2 615 294 227	Washer
14	2 615 294 213	Column	29	2 615 297 216	Bushing
15	2 615 294 214	Shaft	30	2 615 297 204	Plain Washer