


DREMEL®

MODEL: 4300

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	16058065AX	Housing	22	1600A00DM4	Guide Lever
2	2610047644	Field	23	2610003424	Nose Cap
3	1604010B73	Armature	24	1600A009P2	Light Attachment
4	1600A00M8P	Electronic Assembly	26	16058065BV	Cover
5	2610999103	Power Cord	28	2615302548	Grommet
7	2615650007	Cable Clip	29	2610315386	Screw ST3 9x19
8	60829429X4	Label	30	1600A00E0C	Suspension Loop
11	2610017151	Brush Holder	31	4486	Chuck
13	2610009812	Brush Cover	812	2610021241	Carbon Brush
16	1600A011H1	Boot	819	2610044951	Armature Lock

18	2615294035	Cross Recessed Head Screw			
----	------------	---------------------------	--	--	--