


DREMEL®

MODEL: TRIO 6800

F 013 680 049



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	2610004781	Housing	28	2610004794	Locking Lever
2	2610004782	Housing Cover	29	2610004789	Compression Spring
3	2610004825 Special Order Only	Motor	30	2615294035	Cross Recessed-Head Screw
4	2610004830	Speed Governor	31	2610004808	Compression Spring
5	2610999103	Power Supply Cord 240V	32/1	2610004778	Casing Foot
6	2615302548	Grommet	32/2	2610004779	Base Plate
7	2615650007	Cable Clip	32/3	2610004824	Screw
8	2610015215 Deleted by Dremel	Nameplate	32/4	2610011176	Protection
9	2610004802 Deleted by Dremel	Label	33	2610004793 Deleted by Dremel	Wing Screw

22	2610004783	Handle	34	2610930692 Collet Nut Wrench	Adjusting Wrench
23	2610004784	Handle Cover	35	2610007764	Contour Sleeve
24	2610004790	Locking Part	36	2610007765 Deleted by Dremel	Square Nut
25	2610011212	Compression Spring	37	2610011174	Rubber pad
26	2610004791	Trigger	38	2610315386	Screw ST3,9x19
27	2610004797	Compression Spring			