


DREMEL®

MODEL: 1100

3 110 045
 Issued } 06-05-24
 Issue } **Fig./Abb. 1**



Änderungen vorbehalten
 Modifications reserved
 Modificaciones reservadas

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	2610930051	Housing Assembly	826	2610930066	Locking Piece
2	Deleted By Dremel	Motor			
4	Deleted By Dremel	Speed Governor			
19	2610914480	Screw			
22	Deleted By Dremel	Cap			
26	2610014582	Nut			
27	2615110480	Contour Sleeve 1/8"			
28	Deleted By Dremel	Cap			
29	Deleted By Dremel	Pad			
30	Deleted by Dremel	Battery Set			
33	Deleted By Dremel	Pad			

650	2610930692	Chuck Wrench			
651	2610937396	Charger			